



BUNDUCUBE

Mounting hardware/Requirements:

- 1 x 6mm Drill bit
- 4 x M6 x 20mm bolt
- 4 x M6 Nylock nut
- 8 x M6 x 22 washers
- 2 x 10mm spanners/ratchet

Procedure: Mounting the BunduCube

- Place Cube against roof rack/trailer body/mounting area.
- Mark holes through bracket.
- Drill 6mm holes.
- Place Cube bracket over hole.
- Insert bolt with washer.
- Place nut with washer and tighten.

BUNDUCUBE